



Aeotec

## AërQ Temperature & Humidity Sensor 2

SKU: AEOEZWA039



### Quickstart

This is a **secure Alarm Sensor** for **Europe**. To run this device please insert fresh **1 \* CR2477** batteries. Please make sure the internal battery is fully charged.

The device also supports SmartStart. Please scan the QR code on the outlet cover of the device and your controller will add the device automatically when powered up.

### Important safety information

Please read this manual carefully. Failure to follow the recommendations in this manual may be dangerous or may violate the law. The manufacturer, importer, distributor and seller shall not be liable for any loss or damage resulting from failure to comply with the instructions in this manual or any other material. Use this equipment only for its intended purpose. Follow the disposal instructions. Do not dispose of electronic equipment or batteries in a fire or near open heat sources.

### What is Z-Wave?

Z-Wave is the international wireless protocol for communication in the Smart Home. This device is suited for use in the region mentioned in the Quickstart section.

Z-Wave ensures a reliable communication by reconfirming every message (**two-way communication**) and every mains powered node can act as a repeater for other nodes (**meshed network**) in case the receiver is not in direct wireless range of the transmitter.

This device and every other certified Z-Wave device can be **used together with any other certified Z-Wave device regardless of brand and origin** as long as both are suited for the same frequency range.

If a device supports **secure communication** it will communicate with other devices secure as long as this device provides the same or a higher level of security. Otherwise it will automatically turn into a lower level of security to maintain backward compatibility.

For more information about Z-Wave technology, devices, white papers etc, please refer to [www.z-wave.info](http://www.z-wave.info).



### Product Description

This device measures the three air quality parameters temperature, humidity and dew point and reports them to a central controller. Besides this, the device can directly control groups of other Z-Wave devices on over- and undershooting a set temperature and/or humidity parameter. This can be used to establish control loops for temperature and humidity. The device wakes up every 15 minutes to measure the values and it will send unsolicited reports when values change. Additionally, the device will report all values on request. The AërQ Sensor is actively monitoring the danger of mould in a room based on the temperature and humidity and will issue alarm warnings when critical air conditions met. Wireless Alarm and red and a green blinking LED will indicate a mould condition. This local LED warning function is also available when the device is not included in any Z-Wave network and works stand alone.

### Prepare for Installation / Reset

Please read the user manual before installing the product.

In order to include (add) a Z-Wave device to a network it **must be in factory default state**. Please make sure to reset the device into factory default. You can do this by performing an Exclusion operation as described below in the manual. Every Z-Wave controller is able to perform this operation however it is recommended to use the primary controller of the previous network to make sure the very device is excluded properly from this network.

#### Reset to factory default

This device also allows to be reset without any involvement of a Z-Wave controller. This procedure should only be used when the primary controller is inoperable.

Keep the button pressed for 10 seconds. Then the green LED will start blinking. Release the button, when the LED stops blinking. Your device is reset to factory default now.

## Safety Warning for Batteries

The product contains batteries. Please remove the batteries when the device is not used. Do not mix batteries of different charging level or different brands.

## Installation

Just place the device on any flat surface. Please keep in mind that the temperature may be different in different locations inside the room. If placed too close to the heating both temperature, humidity and dew point values may be wrong. The device is IP 20 rated. This means that it must not be exposed to direct water (rain). It is safe to use the device in a humid environment such as a bathroom or dedicated washing facility.

## Inclusion/Exclusion

On factory default the device does not belong to any Z-Wave network. The device needs to be **added to an existing wireless network** to communicate with the devices of this network. This process is called **Inclusion**.

Devices can also be removed from a network. This process is called **Exclusion**. Both processes are initiated by the primary controller of the Z-Wave network. This controller is turned into exclusion respective inclusion mode. Inclusion and Exclusion is then performed doing a special manual action right on the device.

### Inclusion

1. Insert the battery.
2. Press the button quickly three times in a row.

### Exclusion

1. Press the button quickly three times in a row.

## Product Usage

Once the device is powered up it will start monitoring the air parameters and warn of mould using the local red and green LED. Pushing the button will force an immediate measurement and the LEDs will indicate the danger of mould.

- green: no danger of mould in the room
- red: danger of mould, open the windows to lower the humidity

The device contains two sensors with the following accuracy measures:

- Relative Humidity: precision  $\pm 3\%$  RH (max), range 0 to 80% RH
- Temperature: precision  $\pm 0.8$  °C (max), range -10 to 65 °C
- Dew Point: precision  $\pm 0.8$  °C (max), range -10 to 65 °C (calculated from other sensor values)

The device sends the following notifications to the central controller:

- Weather Alarm - Moisture Alarm (0x10 - 0x02)
- Power management - Replace battery now (0x08 - 0x0b)
- Heat Alarm - Overheat Unknown Location (0x04 - 0x02)
- Heat Alarm - Underheat Unknown Location (0x04 - 0x06)

For getting the status of the device on the network you need insert a battery to device. And you see result:

- "The GREEN LED will blink one time in case of success or RED LED will blink five times in case of failure".

## Quick trouble shooting

Here are a few hints for network installation if things dont work as expected.

1. Make sure a device is in factory reset state before including. In doubt exclude before include.
2. If inclusion still fails, check if both devices use the same frequency.
3. Remove all dead devices from associations. Otherwise you will see severe delays.
4. Never use sleeping battery devices without a central controller.
5. Dont poll FLIRS devices.
6. Make sure to have enough mains powered device to benefit from the meshing

## Firmware-Update over the Air

This device is capable of receiving a new firmware 'over the air'. The update function needs to be supported by the central controller. Once the controller starts the update process, perform the following action to confirm the firmware update: Wake Up the device by pressing the central button once.

## Association - one device controls an other device

Z-Wave devices control other Z-Wave devices. The relationship between one device controlling another device is called association. In order to control a different device, the controlling device needs to maintain a list of devices that will receive controlling commands. These lists are called association groups and they are always related to certain events (e.g. button pressed, sensor triggers, ...). In case the event happens all devices stored in the respective association group will receive the same wireless command wireless command, typically a 'Basic Set' Command.

## Association Groups:

| Group Number | Maximum Nodes | Description              |
|--------------|---------------|--------------------------|
| 1            | 5             | Lifeline                 |
| 2            | 5             | Temperature High Trigger |
| 3            | 5             | Temperature Low Trigger  |
| 4            | 5             | Humidity High Trigger    |
| 5            | 5             | Humidity Low Trigger     |
| 6            | 5             | Air Temperature          |

## Configuration Parameters

Z-Wave products are supposed to work out of the box after inclusion, however certain configuration can adapt the function better to user needs or unlock further enhanced features.

**IMPORTANT:** Controllers may only allow configuring signed values. In order to set values in the range 128 ... 255 the value sent in the application shall be the desired value minus 256. For example: To set a parameter to 200 it may be needed to set a value of 200 minus 256 = minus 56. In case of a two byte value the same logic applies: Values greater than 32768 may needed to be given as negative values too.

## Parameter 1: Minimum Temperature change to report

*This value defines the minimum change of temperature to cause an unsolicited report of humidity to the central controller using Lifeline. If the value is set to 0, there will be no reports sent to the controller, when the temperature changes. However, periodic reports, managed by configuration parameter 4, may still be active.*

Size: 1 Byte, Default Value: 20

| Setting | Description |
|---------|-------------|
| 0       | disabled    |
| 1 - 100 | 1/10 degree |

## Parameter 2: Minimum humidity change to report

*This value defines the minimum change of humidity to cause an unsolicited report of humidity to the central controller using Lifeline. If the value is set to 0, there will be no reports sent to the controller, when the humidity changes. However, periodic reports, managed by configuration parameter 4, may still be active.*

Size: 1 Byte, Default Value: 5

| Setting | Description |
|---------|-------------|
| 0       | disabled    |
| 1 - 20  | %           |

## Parameter 3: Check interval for minimum change on parameter 1 and 2.

*This value determines how often aerQ Sensor checks for minimum change in temperature or humidity on Parameter 1 and 2 or when the Sensor wakes up by button pressing.*

Size: 1 Byte, Default Value: 15

| Setting | Description |
|---------|-------------|
| 1 - 255 | Minutes     |

## Parameter 4: Periodic Reports

*This parameter defines the time interval to send an unsolicited report. If the value is set to 0, there will be no periodic reports sent to the controller. However, reports on temperature/humidity changes, managed by configuration parameters 1 and 2, may still be active.*

Size: 2 Byte, Default Value: 43200

| Setting    | Description |
|------------|-------------|
| 0          | disabled    |
| 30 - 65535 | Seconds     |

## Parameter 5: Temperature Upper Watermark value

*This parameter defines a temperature. If the measured temperature surpasses this watermark a BASIC command is sent into Association Group 2*

Size: 2 Byte, Default Value: 0

| Setting  | Description |
|----------|-------------|
| 0        | disabled    |
| 1 - 1000 | 1/10 degree |

#### Parameter 6: Temperature Lower Watermark value

*This parameter defines a temperature. If the measured temperature drops below this watermark a BASIC command is sent into Association Group 3*

Size: 2 Byte, Default Value: 0

| Setting    | Description |
|------------|-------------|
| 0          | disabled    |
| 200 - 1000 | 1/10 degree |

#### Parameter 7: Humidity Upper Watermark value

*This parameter defines a relative humidity. If the measured relative humidity surpasses this watermark a BASIC command is sent into Association Group 4*

Size: 1 Byte, Default Value: 0

| Setting | Description |
|---------|-------------|
| 0       | disabled    |
| 1 - 90  | %           |

#### Parameter 8: Humidity Lower Watermark value

*This parameter defines a relative humidity. If the measured temperature drops below this relative humidity a BASIC command is sent into Association Group 5*

Size: 1 Byte, Default Value: 0

| Setting | Description |
|---------|-------------|
| 0       | disabled    |
| 1 - 90  | %           |

#### Parameter 9: Low Temperature Trigger BASIC Set Command Value

*This defines what BASIC command shall be sent out into association group 3*

Size: 1 Byte, Default Value: 255

| Setting | Description |
|---------|-------------|
| 0 - 255 | Value       |

#### Parameter 10: High Temperature Trigger BASIC Set Command Value

*This defines what BASIC command shall be sent out into association group 2*

Size: 1 Byte, Default Value: 0

| Setting | Description |
|---------|-------------|
| 0 - 255 | Value       |

#### Parameter 11: Low Humidity Trigger BASIC Set Command Value

*This defines what BASIC command shall be sent out into association group 5*

Size: 1 Byte, Default Value: 255

| Setting | Description |
|---------|-------------|
| 0 - 255 | Value       |

#### Parameter 12: High Humidity Trigger BASIC Set Command Value

*This defines what BASIC command shall be sent out into association group 4*

Size: 1 Byte, Default Value: 0

| Setting | Description |
|---------|-------------|
| 0 - 255 | Value       |

**Parameter 13: Offset value for Mold danger notification**

*This value allows to increase the humidity threshold for mold danger notification by max 10%*

Size: 1 Byte, Default Value: 0

| Setting | Description |
|---------|-------------|
| 0 - 10  | %           |

**Parameter 14: Offset value for Temperature**

*Can add or minus this setting value to calibrate temperature when checked. Scale is defined by Param 64. e.g. Value 15 means 1.5C or 1.5F.*

Size: 2 Byte, Default Value: 0

| Setting    | Description           |
|------------|-----------------------|
| -200 - 200 | -20 - 20 ° Steps 0,1° |

**Parameter 15: Offset value for Humidity**

*Can add or minus this setting value to calibrate temperature when checked. Scale is defined by Param 64. e.g. Value 15 means 1.5C or 1.5F.*

Size: 1 Byte, Default Value: 0

| Setting  | Description |
|----------|-------------|
| -50 - 50 | %           |

**Parameter 16: Check interval for Upper/ Lower Watermark value on Parameter 5 ,6,7 and 8.**

*This value determines how often aerQ Sensor checks for upper/lower watermark value in temperature or humidity on Parameter 5 ,6,7 and 8.*

Size: 1 Byte, Default Value: 15

| Setting | Description |
|---------|-------------|
| 1 - 255 | Minutes     |

**Parameter 64: Temperature Scale**

*This parameter sets the temperature scale.*

Size: 1 Byte, Default Value: 1

| Setting | Description |
|---------|-------------|
| 1       | Celsius     |
| 2       | Fahrenheit  |

**Parameter 65: Sensor report after inclusion.**

*This value determines which sensor report will be sent after the inclusion is complete.*

$1+2+4+8=15$

Size: 1 Byte, Default Value: 15

| Setting | Description               |
|---------|---------------------------|
| 1       | Battery Report            |
| 2       | Temperature sensor report |
| 4       | Humidity Sensor report    |
| 8       | Dew point sensor report   |

**Parameter 255: Reset Parameter**

*This parameter helps reset configuration parameters and the device to factory defaults*

Size: 4 Byte, Default Value: 0

| Setting        | Description                                                                 |
|----------------|-----------------------------------------------------------------------------|
| 1 - 4294967294 | Reset all Parameter settings to their default settings.                     |
| 4294967295     | Completely factory reset sensor and send device reset locally notification. |

**Technical Data**

|                                   |                                          |
|-----------------------------------|------------------------------------------|
| <b>Dimensions</b>                 | 34 x 34 x 16 mm                          |
| <b>Hardware Platform</b>          | ZGM130S                                  |
| <b>EAN</b>                        | 1220000017054                            |
| <b>IP Class</b>                   | IP 20                                    |
| <b>Voltage</b>                    | 3V                                       |
| <b>Battery Type</b>               | 1 * CR2477                               |
| <b>Device Type</b>                | Notification Sensor                      |
| <b>Generic Device Class</b>       | GENERIC TYPE SENSOR NOTIFICATION (0x07)  |
| <b>Specific Device Class</b>      | SPECIFIC TYPE NOTIFICATION SENSOR (0x01) |
| <b>Network Operation</b>          | Reporting Sleeping Slave                 |
| <b>Firmware Version</b>           | 02.00                                    |
| <b>Z-Wave Version</b>             | 07.15.1.0                                |
| <b>Certification ID</b>           | ZC12-20080086                            |
| <b>Z-Wave Product Id</b>          | 881.2.9                                  |
| <b>Frequency</b>                  | Europe - 868,4 Mhz                       |
| <b>Maximum transmission power</b> | 5 mW                                     |

## Supported Command Classes

- Sensor Binary (unsec+s2 Unauth+s2 Auth)
- Sensor Multilevel (unsec+s2 Unauth+s2 Auth)
- Multichannel Association (unsec+s2 Unauth+s2 Auth)
- Association Grp Info (unsec+s2 Unauth+s2 Auth)
- Device Reset Locally (unsec+s2 Unauth+s2 Auth)
- Zwaveplus Info (unsec)
- Configuration (unsec+s2 Unauth+s2 Auth)
- Notification (unsec+s2 Unauth+s2 Auth)
- Manufacturer Specific (unsec+s2 Unauth+s2 Auth)
- Powerlevel (unsec+s2 Unauth+s2 Auth)
- Firmware Update Md (unsec+s2 Unauth+s2 Auth)
- Battery (unsec+s2 Unauth+s2 Auth)
- Wake Up (unsec+s2 Unauth+s2 Auth)
- Indicator (unsec+s2 Unauth+s2 Auth)
- Association (unsec+s2 Unauth+s2 Auth)
- Version (unsec+s2 Unauth+s2 Auth)
- Security V2
- Supervision (unsec)
- Transport (unsec)

## Explanation of Z-Wave specific terms

- **Controller** — is a Z-Wave device with capabilities to manage the network. Controllers are typically Gateways, Remote Controls or battery operated wall controllers.
- **Slave** — is a Z-Wave device without capabilities to manage the network. Slaves can be sensors, actuators and even remote controls.
- **Primary Controller** — is the central organizer of the network. It must be a controller. There can be only one primary controller in a Z-Wave network.
- **Inclusion** — is the process of adding new Z-Wave devices into a network.
- **Exclusion** — is the process of removing Z-Wave devices from the network.
- **Association** — is a control relationship between a controlling device and a controlled device.
- **Wakeup Notification** — is a special wireless message issued by a Z-Wave device to announces that is able to communicate.
- **Node Information Frame** — is a special wireless message issued by a Z-Wave device to announce its capabilities and functions.

---

(c) 2025 Z-Wave Europe GmbH, Neefestr. 147, 09116 Chemnitz, Germany, All rights reserved, [www.zwave.eu](http://www.zwave.eu). The template is maintained by [Z-Wave Europe GmbH](#).  
The product content is maintained by Z-Wave Europe GmbH , Supportteam, [support@zwave.eu](mailto:support@zwave.eu). Last update of the product data: 2022-03-21 08:15:06