



Aeotec

Water Sensor 7 Pro

SKU: AEOEZWA019



Quickstart

This is a **secure Alarm Sensor** for **Europe**. To run this device please insert fresh **1 * 1/2 AA** batteries. Please make sure the internal battery is fully charged. Scan the QR code inside the battery compartment of the device and your controller will add the device automatically when powered up.

Important safety information

Please read this manual carefully. Failure to follow the recommendations in this manual may be dangerous or may violate the law. The manufacturer, importer, distributor and seller shall not be liable for any loss or damage resulting from failure to comply with the instructions in this manual or any other material. Use this equipment only for its intended purpose. Follow the disposal instructions. Do not dispose of electronic equipment or batteries in a fire or near open heat sources.

What is Z-Wave?

Z-Wave is the international wireless protocol for communication in the Smart Home. This device is suited for use in the region mentioned in the Quickstart section.

Z-Wave ensures a reliable communication by reconfirming every message (**two-way communication**) and every mains powered node can act as a repeater for other nodes (**meshed network**) in case the receiver is not in direct wireless range of the transmitter.

This device and every other certified Z-Wave device can be **used together with any other certified Z-Wave device regardless of brand and origin** as long as both are suited for the same frequency range.

If a device supports **secure communication** it will communicate with other devices secure as long as this device provides the same or a higher level of security. Otherwise it will automatically turn into a lower level of security to maintain backward compatibility.

For more information about Z-Wave technology, devices, white papers etc, please refer to www.z-wave.info.



Product Description

The AEOTEC Water Sensor 7 Pro is a sensor, which detects water leakage, measures temperature and humidity. The sensor is easily retrofittable.

Thanks to its slim design the AEOTEC Water Sensor 7 Pro can be installed in any bathroom, behind a kitchen sink or in any other tight space. The sensor just has to be installed on the wall and the sensor probe must be put on the floor.

By using the internal temperature and humidity sensor, the device will report on any significant change.

Tripple clicking the tamper button includes (adds) and excludes (removes) the device. A single click on the button will wake up the device. The device supports the Z-Wave Security S2 framework with authenticated and unauthenticated network keys. Please follow the instructions on the central controller when including. The device also supports Smart Start.

Prepare for Installation / Reset

Please read the user manual before installing the product.

In order to include (add) a Z-Wave device to a network it **must be in factory default state**. Please make sure to reset the device into factory default. You can do this by performing an Exclusion operation as described below in the manual. Every Z-Wave controller is able to perform this operation however it is recommended to use the primary controller of the previous network to make sure the very device is excluded properly from this network.

Reset to factory default

This device also allows to be reset without any involvement of a Z-Wave controller. This procedure should only be used when the primary controller is inoperable.

Once Cover is removed and the tamper switch is tripped, push the tamper for 5 seconds until the RED LED blinks once. Then release tamper and push it again for 5 seconds while the RED LED is blinking until the GREEN LED blinks once.

Safety Warning for Batteries

The product contains batteries. Please remove the batteries when the device is not used. Do not mix batteries of different charging level or different brands.

Installation

The sensor can be mounted on the wall. Mounting can be accomplished either using the tape by peeling off the protection foil or using two screws with the holes inside the battery compartment.

Water Sensor probe which is hardwired to the Main Unit must be put on the floor or onto any other surface, where water leakage must be detected.

Inclusion/Exclusion

On factory default the device does not belong to any Z-Wave network. The device needs to be **added to an existing wireless network** to communicate with the devices of this network. This process is called **Inclusion**.

Devices can also be removed from a network. This process is called **Exclusion**. Both processes are initiated by the primary controller of the Z-Wave network. This controller is turned into exclusion respective inclusion mode. Inclusion and Exclusion is then performed doing a special manual action right on the device.

Inclusion

1. Open the housing.
2. Remove the battery protection.
3. Press the tamper on the side of the appliance three times quickly.

Exclusion

1. Open the housing.
2. Press the tamper on the side of the appliance three times quickly.

Product Usage

Once installed the sensor will report Leakage Detected and No Leakage status changes to a central Z-Wave controller using notification commands. Additionally, the sensor can directly control other devices using the association group 2. The device is protected by a tamper switch.

The device contains two sensors with the following accuracy measures:

- Humidity: $\pm 3\%$ RH (max), 0–80% RH
- Temperature: ± 0.4 °C (max), –10 to 85 °C

Water leakage detection

The water leakage detection allows reporting as soon as water hits the sensor probe. This is accomplished using the command class notification - water alarm - water leakage detected unknown location. After the leakage has stopped (the sensor probes are not short-connected through the water) the device reports this to the central controller.

Link testing

When activated by configuration parameter #4 the device can perform a link test with device No.1. Double-clicking the tamper will start the process. As a result, the GREEN LED will blink one time in case of success and RED LED will blink three times in case of failure.

The device sends the following notifications to the central controller:

- Water Leakage Unknown Location (0x05 - 0x02)
- Tamper Removed (0x07 - 0x03)
- Replace Battery Now (0x08 - 0x0b)

Node Information Frame

The Node Information Frame (NIF) is the business card of a Z-Wave device. It contains information about the device type and the technical capabilities. The inclusion and exclusion of the device is confirmed by sending out a Node Information Frame. Beside this it may be needed for certain network operations to send out a Node Information Frame. To issue a NIF execute the following action: Press the tamper once

Quick trouble shooting

Here are a few hints for network installation if things dont work as expected.

1. Make sure a device is in factory reset state before including. In doubt exclude before include.
2. If inclusion still fails, check if both devices use the same frequency.
3. Remove all dead devices from associations. Otherwise you will see severe delays.

4. Never use sleeping battery devices without a central controller.
5. Dont poll FLIRS devices.
6. Make sure to have enough mains powered device to benefit from the meshing

Firmware-Update over the Air

This device is capable of receiving a new firmware 'over the air'. The update function needs to be supported by the central controller. Once the controller starts the update process, perform the following action to confirm the firmware update: **Wake Up the device by removing the cover. Then hit the tamper switch once.**

Association - one device controls another device

Z-Wave devices control other Z-Wave devices. The relationship between one device controlling another device is called association. In order to control a different device, the controlling device needs to maintain a list of devices that will receive controlling commands. These lists are called association groups and they are always related to certain events (e.g. button pressed, sensor triggers, ...). In case the event happens all devices stored in the respective association group will receive the same wireless command, typically a 'Basic Set' Command.

Association Groups:

Group Number	Maximum Nodes	Description
1	5	Lifeline
2	5	Control devices when water leakage is detected
3	5	Sends out alarm message when water leakage is detected
4	5	Sends out alarm messages when tamper is tripped

Configuration Parameters

Z-Wave products are supposed to work out of the box after inclusion, however certain configuration can adapt the function better to user needs or unlock further enhanced features.

IMPORTANT: Controllers may only allow configuring signed values. In order to set values in the range 128 ... 255 the value sent in the application shall be the desired value minus 256. For example: To set a parameter to 200 it may be needed to set a value of 200 minus 256 = minus 56. In case of a two byte value the same logic applies: Values greater than 32768 may needed to be given as negative values too.

Parameter 3: Visual LED Indications

This parameter defines when LEDs will indicate events. Disabling all indications may extend battery life.

Value 0 means - No Indications.

Size: 1 Byte, Default Value: 7 (values 1 + 2 + 4 summarized)

Setting	Description
1	Water Leakage Status Change
2	Wake Up
4	Device Tampering

Parameter 4: Range Test after double click

Allows to enable the activation of a Z-Wave range test with double clicking the tamper switch.

Size: 1 Byte, Default Value: 0

Setting	Description
0	Disabled
1	Enabled

Parameter 5: 2nd Association Group Trigger

This parameter defines the status of the water leakage that causes sending a BASIC command to all devices of Association Group 2.

Size: 1 Byte, Default Value: 0

Setting	Description
0	Switch after Water Leakage Start and Stop
1	Switch after Water Leakage Start
2	Switch after Water Leakage Stop

Parameter 6: Command Sent to Devices of Association Group 2

This parameter defines which commands is sent to 2nd Association Group

Size: 1 Byte, Default Value: 2

Setting	Description
0	On
1	Off
2	On and Off

Parameter 7: BASIC command value sent to 2nd Association Group on On event

This is the BASIC command value sent in case of On event.

Size: 1 Byte, Default Value: 255

Setting	Description
0 - 99	Value
255	Value

Parameter 8: BASIC command value sent to 2nd Association Group on Off event

This is the BASIC command value sent in case of Off event.

Size: 1 Byte, Default Value: 0

Setting	Description
0 - 99	Value
255	Value

Parameter 9: Time Delay of On command frame

On command is sent after a delay defined in this parameter.

Size: 2 Byte, Default Value: 0

Setting	Description
0 - 32400	seconds

Parameter 10: Time Delay of Off command frame

Off command is sent after a delay defined in this parameter.

Size: 2 Byte, Default Value: 0

Setting	Description
0 - 32400	seconds

Parameter 11: Delay of Tamper Alarm Cancellation

Time a tamper alarm is delayed.

Size: 2 Byte, Default Value: 0

Setting	Description
0 - 32400	seconds

Parameter 12: Reporting Tamper Alarm Cancellation

This parameter defines if the alarm cancellation event is reported.

Size: 1 Byte, Default Value: 1

Setting	Description
0	Do not send Report
1	Send Report

Parameter 13: Offset value for Temperature (from version 2.0)

Can add or minus this setting value to calibrate temperature when checked. Scale is defined by Param 64. e.g. Value 15 means 1.5C or 1.5F.

Size: 2 Byte, Default Value: 0

Setting	Description
-200 - 200	-20 - 20 °

Parameter 14: Offset value for Humidity (from version 2.0)

Can add or minus this setting value to calibrate humidity when checked.

Size: 1 Byte, Default Value: 0

Setting	Description
-50 - 50	%

Parameter 15: Threshold Report checks (from version 2.0)

This parameter defines the time interval to check threshold reports via Parameter 16 and 17. If the value is set to 0, there will be no threshold checks. However, reports on Parameter 18 may still be active.

Size: 2 Byte, Default Value: 240

Setting	Description
0	Disabled
30 - 65535	Seconds

Parameter 16: Minimum Temperature change to report

This value defines the minimum change of temperature to cause an unsolicited report of temperature to the central controller using Lifeline.

If the value is set to 0, there will be no reports sent to the controller, when the temperature changes. However, periodic reports, managed by configuration parameter 18, may still be active.

Size: 1 Byte, Default Value: 20

Setting	Description
0	Disabled
1 - 100	1/10 degree

Parameter 17: Minimum humidity change to report

This value defines the minimum change of humidity to cause an unsolicited report of humidity to the central controller using Lifeline.

If the value is set to 0, there will be no reports sent to the controller, when the humidity changes. However, periodic reports, managed by configuration parameter 18, may still be active.

Size: 1 Byte, Default Value: 5

Setting	Description
0	Disabled
1 - 20	%

Parameter 18: Periodic Reports

This parameter defines the time interval to send an unsolicited report.

If the value is set to 0, there will be no periodic reports sent to the controller. However, reports on temperature/humidity changes, managed by configuration parameters 16 and 17, may still be active.

Size: 2 Byte, Default Value: 43200

Setting	Description
0	Disabled
900 - 65535	Seconds

Parameter 22: Enalbe/ disbale Binary Sensor report (from version 2.0)

Backwards compatibility, Binary Sensor for door/window state. (Sensor type=0x0A)

Size: 1 Byte, Default Value: 0

Setting	Description
0	Disable
1	Enable

Parameter 23: Report low battery report when level goes under threshold setting (from version 2.0)

Size: 1 Byte, Default Value: 20

Setting	Description
10 - 50	%

Parameter 24: Report battery report at an interval set in hour (from version 2.0)

Size: 1 Byte, Default Value: 24

Setting	Description
0	Disable
1 - 255	Hours

Parameter 64: Temperature Scale

This parameter sets the temperature scale.

Size: 1 Byte, Default Value: 1

Setting	Description
1	Celsius
2	Fahrenheit

Parameter 255: Reset Parameter

This parameter helps reset configuration parameters and the device to factory defaults

Size: 4 Byte, Default Value: 0

Setting	Description
1 - 1431655764 (0x55555554)	Reset all Parameter settings to their default settings.
1431655765	Completely factory reset sensor and send device reset locally notification.

Technical Data

Dimensions	28x95x35 mm
Hardware Platform	ZGM130S
EAN	1220000016729
IP Class	IP 20
Battery Type	1 * 1/2 AA
Device Type	Notification Sensor
Generic Device Class	Sensor Notification
Specific Device Class	Routing Sensor Notification
Network Operation	Reporting Sleeping Slave
Firmware Version	02.00
Z-Wave Version	07.12
Certification ID	ZC12-20060075
Z-Wave Product Id	0371.0002.0013
Frequency	Europe - 868,4 Mhz
Maximum transmission power	5 mW

Supported Command Classes

- Association (unsec+s2 Unauth+s2 Auth)
- Association Grp Info (unsec+s2 Unauth+s2 Auth)
- Battery (unsec+s2 Unauth+s2 Auth)
- Configuration (unsec+s2 Unauth+s2 Auth)
- Device Reset Locally (unsec+s2 Unauth+s2 Auth)
- Firmware Update Md (unsec+s2 Unauth+s2 Auth)
- Indicator (unsec+s2 Unauth+s2 Auth)
- Manufacturer Specific (unsec+s2 Unauth+s2 Auth)
- Multi Channel Association (unsec+s2 Unauth+s2 Auth)
- Sensor Multilevel (unsec+s2 Unauth+s2 Auth)
- Notification (unsec+s2 Unauth+s2 Auth)
- Powerlevel (unsec+s2 Unauth+s2 Auth)
- Security 2
- Supervision (unsec);
- Transport Service (unsec)
- Version (unsec+s2 Unauth+s2 Auth)
- Wake Up (unsec+s2 Unauth+s2 Auth)
- Zwaveplus Info (unsec)

Explanation of Z-Wave specific terms

- **Controller** — is a Z-Wave device with capabilities to manage the network. Controllers are typically Gateways, Remote Controls or battery operated wall controllers.
- **Slave** — is a Z-Wave device without capabilities to manage the network. Slaves can be sensors, actuators and even remote controls.
- **Primary Controller** — is the central organizer of the network. It must be a controller. There can be only one primary controller in a Z-Wave network.
- **Inclusion** — is the process of adding new Z-Wave devices into a network.
- **Exclusion** — is the process of removing Z-Wave devices from the network.
- **Association** — is a control relationship between a controlling device and a controlled device.
- **Wakeup Notification** — is a special wireless message issued by a Z-Wave device to announces that is able to communicate.
- **Node Information Frame** — is a special wireless message issued by a Z-Wave device to announce its capabilities and functions.

(c) 2025 Z-Wave Europe GmbH, Neefestr. 147, 09116 Chemnitz, Germany, All rights reserved, www.zwave.eu. The template is maintained by [Z-Wave Europe GmbH](#).
The product content is maintained by Z-Wave Europe GmbH , Supportteam, support@zwave.eu. Last update of the product data: 2021-12-06 14:41:33