


DREO | Air Purifier

Macro AP606

USER MANUAL



”

Thanks for Choosing DREO!

Your support means the world to us.
We hope you enjoy our product as much as
we did creating it.

CONTENT

01

IMPORTANT SAFETY
INSTRUCTIONS

1-2

02

KNOWING YOUR
APPLIANCE

3

03

USING YOUR
APPLIANCE

4-6

04

CLEANING AND
MAINTENANCE

7-9

05

TROUBLESHOOTING

10-12

06

DREO CUSTOMER
CARE

13-14

IMPORTANT SAFETY INSTRUCTIONS

01



READ ALL CAUTIONARY MARKINGS ON THE APPLIANCE AND SAFETY INSTRUCTIONS IN THE USER MANUAL BEFORE USE.



WARNING:
In order to avoid overheating, do not cover the appliance.

Do not use the appliance near flammables and combustibles.

General Safety

1. Use the appliance as described in the user manual only. Any other use not recommended in the user manual may cause fire, electrical shock, or personal injury.
2. Children shall not play with the appliance. Cleaning and maintenance shall not be performed by children without supervision.
3. This appliance can be used by children aged above 8 years and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of this appliance in a safe way and understand the hazards involved.

Location Safety

1. Always place the appliance on a level, stable and dry surface.
2. Keep the appliance away from heat sources to avoid fire hazards.
3. Do not place the appliance in excessively humid environments.
4. Do not place the appliance directly on or against soft furnishings such as beddings or curtains. Doing so could cause blockage of the openings.
5. Do not use the appliance outdoors, or in toxic or explosive environments, or where flammable or combustible gases are present.
6. Allow at least 15" /38 cm of clearance on all sides of the appliance.

Operation Safety

1. Do not immerse in water and any other liquids.
2. Do not plug in or operate the appliance with wet hands.
3. Do not sit, stand or place heavy objects on the appliance.

4. Do not insert your fingers, pencil and any other objects into any openings.
5. Do not attempt to repair or modify any electrical or mechanical functions on the appliance. Doing so will void your warranty. All servicing should be performed by qualified personnel only.

Electricity Safety

1. Make sure that the voltage of your electricity supply is the same as that indicated on the appliance.
2. Always unplug before cleaning or leaving the appliance unused for a long period of time. Keep your hands dry when plugging/unplugging.
3. Do not operate this appliance with a damaged cord or plug. Discard this appliance or return to an authorized service facility for examination and/or repair.
4. Do not run cord under carpeting. Do not cover cord with throw rugs, runners, or similar coverings. Do not route cord under furniture or appliances. Keep the cord out of areas where people walk often. Place the cord where it will not be tripped over.
5. To avoid fire or shock hazard, plug the appliance directly into a wall outlet.
6. **WARNING:** To Reduce The Risk Of Fire, Electric Shock Or Injury To Persons, Do Not Use Replacement Parts That Have Not Been Recommended By The Manufacturer (e.g. Parts Made At Home Using A 3D Printer).
7. **WARNING:** To Reduce The Risk Of Fire Or Electric Shock, Do Not Use This Fan With Any Solid-State Speed Control Device.
8. This appliance has a polarized plug (one blade is wider than the other). To reduce the risk of electric shock, this plug is intended to fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not attempt to defeat this safety feature.

FOR HOUSEHOLD USE ONLY READ AND SAVE THESE INSTRUCTIONS

Gentle Reminder:



Check the appliance regularly and refer to TROUBLESHOOTING or contact our customer support if it shows any of the following signs:

- Power cord or plug is damaged.
- Loud noise, unusual smell or excessive heat.


Specifications

Model No.	DR-HAP006
Input	120V~60Hz
Weight	4.63lb/2.1kg

KNOWING YOUR APPLIANCE

02


Package Contents




USING YOUR APPLIANCE

03


Before Use




Put it upside down. Rotate the bottom cover to unlock and take the cover off.



Remove the filter from its packaging then put the filter back.



Rotate the bottom cover clockwise to lock back in place.



Return to upright position on a flat, stable, and clear surface, plug the appliance into the power outlet.

Control Panel



Power Button

Turn power on/off



Purifying Speed Button

Adjust fan speed across 1-4 levels



Auto Mode Button

- Purify and adjust purifying speed automatically based on air quality conditions.
- Long press for 5 seconds to reset the Filter Life Indicator.



Sleep Mode Button

Touch to purify the air at the most silent power setting.



Timer Button

- Select to set a timer (0-12 hours)
- Long press for 3 seconds to activate/deactivate the child lock function.

Note: The timer hour is shown on the LED display.




LED Light Button

Turn the LED light on/off for the display or air quality indicator.

LED Display

Constantly monitor the air quality in your room with the comprehensive and intuitive monitor display.

Note: You can turn off the LED display and lights using the  button.



Air Quality Indicator Light

Light Color	Air Quality Level
Blue	Excellent
Green	Good
Orange	Moderate
Red	Poor

Note:

The Air Quality Sensor detects PM 2.5 particles but cannot detect odors. If you feel that the indoor air odor is relatively strong, it is recommended to manually open the highest purifying speed.

Additional Features



Child Lock

- Long press  for 3 seconds to activate/deactivate the child lock function.
- When activated, the display will flash 

On/Off Timer

When the appliance is ON/OFF, touch the timer button repeatedly to set a timer (from 0-12H) for the appliance to turn ON/OFF.



Memory

If the appliance is turned OFF or disconnected from power, it will operate under the previous settings (except the Child Lock function/timer setting) when it is turned ON again.



Display turns off after 5 seconds in Sleep Mode.
Wake up the display with any button.

Getting the Most Out of Your Air Purifier



1. Keep the doors and windows closed when the air purifier is on.
2. Do not block the air openings and keep away from curtains or walls.
3. Maintain and replace the filter on a regular basis for maximum efficiency.

CLEANING AND MAINTENANCE

05

Replacing the Filter


The filter life is measured by the air purifier's algorithm which is based on the working mode, fan speed, run time, and indoor air quality. It's recommended to replace the filter every 6-8 months or when the Filter Life Indicator alerts.

1




The Filter Life Indicator will flash when the filter needs to be replaced. Turn off and unplug the air purifier.

2




Rotate the bottom cover to unlock then take the cover off.

3



Remove the plastic pacakging.

4



Remove the old filter then put the new filter in place.

5



Rotate the bottom cover clockwise to lock back in place.


6



Return to upright position and long press the  for 5 seconds until it beeps, to reset the Filter Life Indicator.


Cleaning the Inside & Outside

1



Unplug the air purifier before any cleaning and maintenance.

2



Remove the filter and clean the inside with a dust vacuum.


3



Wipe clean the housing with a dry, soft, non-abrasive cloth.

Cleaning the Filter

- For optimal use, the outer pre-filter can be cleaned with a soft, dry brush once every 2-4 weeks.
- Keep away from water and humid areas. Moisture will allow mold to grow.



TROUBLESHOOTING

06

Related to Filter

Where can I buy a new filter?

Please purchase directly from the DREO official website at www.dreo.com or through the DREO app.

I changed the filter, but the Filter Change Reminder is still on.

The Filter Life Indicator will not automatically reset. Please press and hold the  Filter Reset button to reset the reminder, the indicator will turn off after reset.

The Filter Change Reminder has not turned on for a long period of time.

There are several factors that can impact the filter life, including the indoor air quality level, length of operation and particle density in the air. If your room has a better air quality level and/or you don't use your air purifier often, the reminder will take longer to light up.

Related to Use

Why is my air purifier not working?

Check if the power is connected, the power cord is damaged, or the electrical outlet is powered.

The airflow from my air purifier is too weak.

- Make sure that there is enough space around the air purifier.
- Check if the filter packaging has been removed.
- Fan speed will be low when auto mode is switched on and air quality is good. Try to switch to higher speed.
- Replace the filter if the filter is clogged and overloaded.

My air purifier doesn't improve the air quality.

- Check if the filter packaging has been removed.
- Use within 183 ft² areas for optimal air refresh rate (4.8X air changes per hour).
- Make sure the windows are closed as polluted air may continue coming in from outside of the windows.
- The overloaded filter will make the fan work harder to pass the air through. Consider replacing the filter if it is clogged.
- Do not place in crowded areas and corners.
- Check if air outlet and inlet are obstructed.

Why is my air purifier making a loud noise?

- Switch the air purifier to sleep mode or lower purifying speeds.

Why is the Air Quality indicator is always red?

- It's recommended to move the appliance to a different location, replug it, and check the indicator light again. If the issue persists, please contact our Customer Support.

The odor in the room is very strong, but the Air Quality Indicator is only green or blue.

- The Air Quality Sensor detects PM 2.5 particles but cannot detect odors. If you feel that the indoor air odor is relatively strong, it is recommended to manually open the highest purifying speed.

Why is the Air Quality indicator always blue?

- The Air Quality sensor reports the presence of airborne particles, but it cannot detect gas. Please make sure there is no gas contamination inside your room.

Why is my air purifier making an unusual noise?

- Make sure the air purifier is operating on a flat, stable surface.
- Do not add essential oils or diffusers into the air purifier or use in a excessively humid area. Humidity will cause mold to grow.
- If the unusual noise still exists, there may be external objects blocking the air openings. Please contact our customer support.

Why does my air purifier produce an unpleasant smell?

- During the initial few days, new air purifiers produce a plastic smell which is normal and will dissipate eventually.
- Do not add essential oils or diffusers into the air purifier or use in a excessively humid area. Humidity will cause mold to grow.
- If the filter has absorbed pollutants to its maximum capacity, then the smell may come from the dirty filter. Please replace the filter when necessary.

If your problem is not listed or still persists, contact our Customer Support (see page 14).

12-MONTH LIMITED WARRANTY

What is Covered

DREO warrants to you that your product will be free from original defects in materials and workmanship for a period of twelve (12) months from the date of your purchase, when you use your product for intended purposes in accordance with this User Manual.

Please retain your proof of purchase. If you do not retain your proof of purchase, your warranty will start two (2) months from the date of manufacture printed on your product label.

What is Not Covered

This limited warranty only applies to the original purchaser of your product and is non-transferable. This warranty is only valid if your product is used in the country in which you originally purchased it. In addition, this warranty will not apply, and DREO will not be liable for any costs, damages, or repairs, in connection with any of the following:

- Accidents or use of your product with inappropriate force;
- Damage or destruction caused by wrong voltage or unstable electric current;
- Normal wear and tear;
- Careless operation or handling, misuse, abuse, neglect, and/or failure to maintain or use your product in accordance with this User Manual;
- Any partially or completely altered, modified and/or dismantled products;
- Reduction in battery discharge time due to battery age or use (as applicable);
- Products with altered or removed serial numbers;
- Clearing any blockages from the product;
- Purchases from retailers and distributors not authorized by DREO to sell this product;
- Defects caused by or resulting from damages from shipping or handling by any third party not authorized by DREO to ship or handle your product; or
- Defects caused by or resulting from repairs, service, improper maintenance, or alteration to your product or any of its components by anyone other than a repair person authorized by DREO.

Any service and customer support that DREO provides to you under this limited warranty will not extend the duration of this limited warranty.

Warranty Limitations and Exclusions

ANY IMPLIED WARRANTIES RELATING TO YOUR PRODUCT, INCLUDING BUT NOT LIMITED TO THE WARRANTY OF MERCHANTABILITY AND THE WARRANTY OF FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED TO THE DURATION OF THE LIMITED WARRANTY SET FORTH ABOVE AND ARE OTHERWISE DISCLAIMED.

THIS LIMITED WARRANTY SHALL BE THE SOLE REMEDY OF THE PURCHASER OR USER OF THE PRODUCT, AND DREO SHALL NOT BE LIABLE FOR AN ALLEGEDLY DEFECTIVE OR DAMAGED PRODUCT EXCEPT TO REPAIR OR REPLACE IT IN ACCORDANCE WITH THIS LIMITED WARRANTY. DREO WILL NOT BE LIABLE FOR SPECIAL, INCIDENTAL, INDIRECT, CONTINGENT, OR CONSEQUENTIAL DAMAGES OR LOSSES OF ANY NATURE THAT YOU MAY INCUR IN CONNECTION WITH YOUR PURCHASE OR USE OF YOUR PRODUCT.

Some jurisdictions do not allow limitations on how long an implied warranty lasts or the exclusion or limitation of incidental or consequential damages, so the above limitations or exclusions may not apply to you. This limited warranty gives you specific legal rights, and you also may have other rights which vary from jurisdiction to jurisdiction.

Limited Remedies

If your product fails because of an original defect in material and/or workmanship during the warranty period, DREO will repair or replace (in DREO's sole discretion) your product.

To obtain warranty service on your product, contact us at support@dreo.com or at (888) 290-1688 (available from Monday-Friday, 9:00 AM-5:00 PM PST/PDT) for further instructions.

IN THE EVENT OF AN ORIGINAL DEFECT IN MATERIAL AND/OR WORKMANSHIP, TO THE EXTENT PERMITTED BY LAW, THE REMEDIES SET FORTH IMMEDIATELY ABOVE ARE YOUR SOLE AND EXCLUSIVE REMEDIES.

FCC Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Please note that changes or modifications of this product is not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 18 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Model No.: DR-HAP006
Rev_1.1_EN

We're Here to Help!

-  (888) 290-1688 (Mon - Fri, 9:00 am-5:00 pm PST/PDT)
-  www.dreo.com
-  support@dreo.com



www.dreo.com

Looking for help?

Contact us to get expert support.



support@dreo.com



[\(888\) 290-1688](tel:(888)290-1688)



www.dreo.com

Mon-Fri, 9:00 am-5:00 pm PST/PDT